

EXAMPLE 1 CONTRACTOR OF CONTRACTOR OF CONTRACTOR OF CONTRACTOR OF CONTRACT ON CONTRACT OF CONTRACT O

NOTE: Kits include Rear Frames and Front Frame Brackets where applicable.

TABLE OF CONTENTS: PREPARE CAR FOR INSTALLATION:

- Step 1 Install Front Frame Brackets
- Step 2 Install Rear Frames
- Step 3 Install Track Tops
- Step 4 Secure Top to Rear Frames
- Factory Top
- Top Supports/Drain Tubes
- Rear Frames Bench Back Cushion
 - Bag Rack Assembly

Remove the following:

NOTE: Save original hardware for later use.

IMPORTANT: Do not fully tighten hardware until instructed. Read through all instructions before beginning installation.

STEP

STEP

MADE IN THE

WITH PRIDE

INSTALL SEAT PLATES & REAR FRAMES

INSTALL FRONT FRAME BRACKETS

FOR USE WITH DOUBLETAKE REAR SEAT KITS — FITS: CLUB CAR DS & PRECEDENT / E-Z-GO TXT & RXV / YAMAHA G14-G19, DRIVE, & DRIVE 2. EACH CAR MODEL HAS UNIQUE SEAT BACK SUPPORTS, BUT ALL REAR FRAMES MOUNT THE SAME. INSTALLATION IS PICTURED ON A CLUB CAR PRECEDENT.

UNIVERSAL SEAT PLATES

2

For ease of installation install Universal Seat Plates onto Seat Back Supports before installing Rear Frames. **See the Seat Plate Kit Instructions** for mounting to Seat Back Supports.

Mount Front Frame Brackets to Top Frame according to your car model. (SEE INSTRUCTIONS INCLUDED WITH FRONT FRAME BRACKET KIT)



REAR FRAMES

Mount the Rear Frames, to the Seat Back Supports, with the top bent legs facing to the rear of the car. **NOTE: Leave HW loose until Top is installed**.



3

Rest the Top on Front & Rear Frames, attach to Front Frames with provided hardware. ** Place Rubber Washers (F) between Brackets & Frames when installing **

CLUB CAR DS & PRECEDENT / YAMAHA DRIVE & DRIVE 2



E-Z-GO TXT

Mount to inside holes with hardware (E & F). — Fully tighten Hardware.



E-Z-GO RXV

Mount to 2nd hole from inside with hardware (E & F). — Fully tighten Hardware.







SECURE TOP TO REAR FRAMES

- **IMPORTANT**: *Place Scrap Material between Top Frame & Top before drilling.*
- Clamp Rear Frame to Top Frame. Double check Rear Frame positioning (plumb/level) and chase drill holes through Rear Frame and Top Frame (H) using 1/4" drill bit.
- Attach Rear Frame with Hardware (I & F) Fully tighten Hardware. Repeat for opposite side.
- ** Place Rubber Washers (F) between Brackets & Frames when installing **

ALL CAR MODELS - REAR FRAMES

4

— Fully tighten Hardware.





NOTE: Fully tighten Rear Frame hardware to Seat Back Supports.

STEP 5 SECURE TOP TO CENTER SUPPORTS - (CENTER SUPPORTS INCLUDED WITH LIMO POD)

IMPORTANT: Place Scrap Material between Top Frame & Top before drilling.

- Position the Center Support on Top Frame (plumb/level) and chase drill hole through Top Frame (J) using 1/4" drill bit.
- Attach Center Support with Hardware (I & F) Fully tighten Hardware. Repeat for opposite side.
- ** Place Rubber Washers (D) between Brackets & Frames when installing **

ALL CAR MODELS - CENTER SUPPORTS







(This page left blank intentionally)