



LGT-137

RHOX Self-Canceling Plug & Play Turn Signal Designed for RHOX Plug & Play Wire Harnesses Installation Instructions



Caution: Please read through the instructions carefully. Before starting this project, remove the system's positive and negative connections from the battery or battery pack. This kit is designed for a 12-48V operation only. Operating this kit at a higher voltage will void any and all warranties.

Turn Signal Switch Hardware

a-d

Contents		QTY
a	Adhesive Backed Rubber Inserts, 5mm Thick	4
b	Adhesive Backed Rubber Inserts, 3mm Thick	4
c	Adhesive Backed Rubber Inserts, 2mm Thick	4
d	Adhesive Backed Rubber Inserts, 1mm Thick	4
e	Plastic Wire Ties (Not Shown)	10

Tools Needed for Installation

- Screwdriver (Phillips)


Before You Start

1. Turn Key OFF.
2. Place Tow/Run Switch in Tow if equipped.
3. Remove the system's positive and negative connections from the battery/battery pack.
4. Engage the parking brake.


Self-Canceling Turn Signal Installation

NOTE: If installing a steering column cover, do so before installing the turn signal.

1. Remove the mounting collar from the turn signal housing. Determine which set of rubber inserts best fits for a snug fit around the steering column.




2. Remove the paper backing from the selected inserts and adhere the (4) inserts firmly in place on both sides of the housing. Center inserts in channels for the best fitment.
3. Mount the turn signal assembly in a convenient location on the steering column using the included rubber inserts and hardware as shown.



4. Carefully route the turn signal harness down the left side of the steering column and behind the dash.

NOTE: The (3) control boxes can be removed if needed for routing purposes. Reinstall these once the harness is behind the dash compartment.



5. Remove the jumper harness from the 9-pin turn signal connector on the RHOX plug and play harness. Retain the jumper harness.



6. Connect the 9-pin connector on the turn signal to the 9-pin connector labeled "Connect to Turn Signal" on the plug & play harness.



To 9-Pin Connector
on P&P Harness

7. Connect the female bullet connector with the gray wire on the turn signal harness to the male bullet connector on the plug & play harness labeled "+12V Dimmer".
8. If the headlights contain color accent lights, connect the female bullet connector with the red/green wire to the bullet connector labeled "Connect for Turn Signal Controlled Accent Lights" on the plug and play harness.



Connect for
High / Low Beam



Connect for
Accent Light Control

9. Disconnect the push-pull switch from the plug and play harness as it will not be used with the T5. Replace it with the small jumper harness included in the kit. Retain push-pull switch.

NOTE: The T5 turn signal will control the ON/OFF function of the light kit.



Push-Pull Switch

Jumper

10. Locate a flat, level part of the frame to mount the self-canceling module. Clean the area well with alcohol. Peel off the protective backing on the module and adhere it to the frame. Secure the module with a self-tapping screw (not included). The arrow on the module should face towards the front of the cart. The side with the word "Forward" should face up.


NOTE: An extension harness is included with the kit to use if needed to reach the desired mounting area.



11. Test the functionality of the turn signal.
12. Secure any loose wires behind the dash.
13. For a completed look, add a turn signal switch wire cover (sold separately) over the turn signal wire harness and steering column.

LGT-105: Adjustable Steering Column Cover (Extends to 17", No Cutting Required)
LGT-107A: Universal Steering Column Cover (Cut to Size)

Turn Signal Features and Functions



* Only available on RHOX HIGH/LOW beam enabled LED headlights.
** Only available on RHOX LED headlights that include accent lights.

Your Self-Canceling Turn Signal Kit is now complete.
Please enjoy safely!

Scan QR code or use the link to view our installation video library.
<https://www.youtube.com/user/golfcartinstructions>

